



SERVICE MANUAL LS-Series Subwoofers

WEB ACCESS: http://www.yorkville.com

WORLD HEADQUARTERS CANADA

Yorkville Sound

550 Granite Court Pickering, Ontario L1W-3Y8 CANADA

Voice: (905) 837-8481 Fax: (905) 837-8746

U.S.A.

Yorkville Sound Inc.

4625 Witmer Industrial Estate Niagara Falls, New York 14305 USA

> Voice: (716) 297-2920 Fax: (716) 297-3689



Quality and Innovation Since 1963
Printed in Canada

IMPORTANT SAFETY INSTRUCTIONS





INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK).

NO USER SERVICEABLE PARTS INSIDE.

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Read Instructions

The Owner's Manualshould be read and understood before operation of your unit. Please, save these instructions for future reference.

Packaging

Keep the box and packaging materials, in case the unit needs to be returned for service.

Warning

When using electric products, basic precautions should always be followed, including the following:

Power Sources

Your unit should be connected to a power source only of the voltage specified in the owners manual or as marked on the unit. This unit has a polarized plug. Do not use with an extension cord or receptacle unless the plug can be fully inserted. Precautions should be taken so that the grounding scheme on the unit is not defeated.

Hazards

Do not place this product on an unstable cart, stand, tripod, bracket or table. The product may fall, causing serious personal injury and serious damage to the product. Use only with cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Follow the manufacturer's instructions when installing the product and use mounting accessories recommended by the manufacturer.

The apparatus should not be exposed to dripping or splashing water; no objects filled with liquids should be placed on the apparatus.

Terminals marked with the "lightning bolt" are hazardous live; the external wiring connected to these terminals require installation by an instructed person or the use of ready made leads or cords.

Ensure that proper ventilation is provided around the appliance.

No naked flame sources, such as lighted candles, should be placed on the apparatus.

Power Cord

The AC supply cord should be routed so that it is unlikely that it will be damaged. If the AC supply cord is damaged DO NOT OPERATE THE UNIT.

Service

The unit should be serviced only by qualified service personnel.

INSTRUCTIONS RELATIVES AU RISQUE DE FEU, CHOC ÉLECTRIQUE, OU BLESSURES AUX PERSONNES

AVIS:

AFIN DE REDUIRE LES RISQUE DE CHOC ELECTRIQUE, N'ENLEVEZ PAS LE COUVERT (OU LE PANNEAU ARRIERE) NE CONTIENT AUCUNE PIECE REPARABLE PAR L'UTILISATEUR.

CONSULTEZ UN TECHNICIEN QUALIFIE POUR L'ENTRETIENT

Veuillez Lire le Manuel

Il contient des informations qui devraient êtres comprises avant l'opération de votre appareil. Conservez S.V.P. ces instructions pour consultations ultérieures.

Emballage

Conservez la boite au cas ou l'appareil devait être retourner pour réparation.

Attention:

Lors de l'utilisation de produits électrique, assurezvous d'adhérer à des précautions de bases incluant celle qui suivent:

Alimentation

L'appareil ne doit être branché qu'à une source d'alimentation correspondant au voltage spécifié dans le manuel ou tel qu'indiqué sur l'appareil. Cet appareil est équipé d'une prise d'alimentation polarisée. Ne pas utiliser cet appareil avec un cordon de raccordement à moins qu'il soit possible d'insérer complètement les trois lames. Des précautions doivent êtres prises afin d'eviter que le système de mise à la terre de l'appareil ne soit désengagé.

Risque

Ne pas placer cet appareil sur un chariot, un support, un trépied ou une table instables. L'appareil pourrait tomber et blesser quelqu'un ou subir des dommages importants. Utiliser seulement un chariot, un support, un trépied ou une table recommandés par le fabricant ou vendus avec le produit. Suivre les instructions du fabricant pour installer l'appareil et utiliser les accessoires recommandés par le fabricant.

Il convient de ne pas placer sur l'appareil de sources de flammes nues, telles que des bougies allumées.

L'appeil ne doit pas être exposé à des égouttements d'eau ou des éclaboussures et qu'aucun objet rempli de liquide tel que des vases ne doit être placé sur l'appareil.

Assurez que lappareil est fourni de la propre ventilation.

Les dispositifs marqués d'une symbole "d'éclair" sont des parties dangereuses au toucher et que les câblages extérieurs connectés à ces dispositifs de connection extérieure doivent être effectivés par un opérateur formé ou en utilisant des cordons déjà préparés.

Cordon d'Alimentation

Évitez d'endommager le cordon d'alimentation. N'UTILISEZ PAS L'APPAREIL si le cordon d'alimentation est endommagé.


Service


Consultez un technicien qualifié pour l'entretien de votre appareil.


Parts List 12/6/2005

YS# Description Qty.	YS # Description	Qty.	YS#	Description	Qty.	YS# Description	Qty.
LS608	LS808			LS1004		LS1208	
8483 ADAPTOR, SPEAKER STAND, METAL, BLACK	1 8483 ADAPTOR, SPEAKER STAND, METAL, BLACK	1	8545	RECESSED RUBBER BUMPER WITH WASHER	2	8545 RECESSED RUBBER BUMPER WITH WASHER	2
8547 PLASTIC FOOT BLACK, POLYETHYLENE	8545 RECESSED RUBBER BUMPER WITH WASHER	2	8562	CORNER, 3 LEGS, BLACK OXIDE	2	8562 CORNER, 3 LEGS, BLACK OXIDE	
8562 CORNER, 3 LEGS, BLACK OXIDE	8562 CORNER, 3 LEGS, BLACK OXIDE	4	8569	CORNER, 2 LEGS NO LIP BLACK OXIDE	4	8569 CORNER, 2 LEGS NO LIP BLACK OXIDE	
8569 CORNER, 2 LEGS NO LIP BLACK OXIDE	8569 CORNER, 2 LEGS NO LIP BLACK OXIDE	2	8579	4000 SERIES RIGID CASTER	2	8579 4000 SERIES RIGID CASTER	2
3924 1/4" JCK PCB MT VERT 2XTIP HICURNT	8579 4000 SERIES RIGID CASTER	2	3924	1/4" JCK PCB MT VERT 2XTIP HICURNT	2	3924 1/4" JCK PCB MT VERT 2XTIP HICURNT	2
3628 SPKON 4C PCB MT VERT 250TAB GRY #4	3924 1/4" JCK PCB MT VERT 2XTIP HICURNT	2	3628	SPKON 4C PCB MT VERT 250TAB GRY #4	2	3628 SPKON 4C PCB MT VERT 250TAB GRY #4	- 2
8515 SMALL BLACK XOVERDISH PLASTIC CNFG1	1 3628 SPKON 4C PCB MT VERT 250TAB GRY #4	2		SMALL BLACK XOVERDISH PLASTIC CNFG1	1	8515 SMALL BLACK XOVERDISH PLASTIC CNFG1	
8565 BAR HANDLE ALL METAL	8515 SMALL BLACK XOVERDISH PLASTIC CNFG1	1		BAR HANDLE RIGHT ANGLE TOP LOAD	2	8551 BAR HANDLE RIGHT ANGLE TOP LOAD	- 2
8604 10-32 T NUT	8551 BAR HANDLE RIGHT ANGLE TOP LOAD	1		BAR HANDLE ALL METAL	2	8565 BAR HANDLE ALL METAL	-
8515DS ALUMINIZED DECAL FOR 8515 SUBS ONLY	8565 BAR HANDLE ALL METAL	2		10-32 T NUT	16	8604 10-32 T NUT	8
8259D "Y" LOGO ELITE SERIES LARGE DOMED	1 8604 10-32 T NUT	8		CABINET COVER, BLACK, 54" WIDE	37.92	3803 NYLON SECUR-A-TACH MINI PLASTIC TIE	- 1
3543 20 PIN BRKAWAY 90 LOCK .156 0.3		1		NYLON SECUR-A-TACH MINI PLASTIC TIE	1	8515DS ALUMINIZED DECAL FOR 8515 SUBS ONLY	- 1
3549 TRIFURCON TERM .156	8515DS ALUMINIZED DECAL FOR 8515 SUBS ONLY	1		ALUMINIZED DECAL FOR 8515 SUBS ONLY	1	8259D "Y" LOGO ELITE SERIES LARGE DOMED	
3558 TERM HOUSING 4 CIR .156/RAMP	8259D "Y" LOGO ELITE SERIES LARGE DOMED	1		"Y" LOGO ELITE SERIES LARGE DOMED	1	3543 20 PIN BRKAWAY 90 LOCK .156	0.2
4597 22AWG STRAN TC WIR JMP 10	3543 20 PIN BRKAWAY 90 LOCK .156	0.2		20 PIN BRKAWAY 90 LOCK .156	0.2	3549 TRIFURCON TERM .156	0.1
8729 #4 X 3/8 FLAT QUAD TYPE A JS500 BLK	4 3549 TRIFURCON TERM .156	0.2		TRIFURCON TERM .156	2.2	3558 TERM HOUSING 4 CIR .156/RAMP	
8801 6-32 X 3/8 PAN PH TAPTITE JS500	3558 TERM HOUSING 4 CIR .156/RAMP	1		TERM HOUSING 4 CIR .156/RAMP	1	8602 1/4-20 T NUT	26
8811 #6 X 1 1/4 FLAT QDRX WS LR CLEAR ZN	3 4597 22AWG STRAN TC WIR JMP	40		1/4-20 T NUT	10	4597 22AWG STRAN TC WIR JMP	10
		10			10		- 10
8785 #8 X 3/4 OVAL PH TYPE A BLACK OXIDE	8729 #4 X 3/8 FLAT QUAD TYPE A JS500 BLK	4		22AWG STRAN TC WIR JMP	10	8729 #4 X 3/8 FLAT QUAD TYPE A JS500 BLK	- 4
8815 8-32 X 3/4 PAN PH TAPTITE JS500	4 8801 6-32 X 3/8 PAN PH TAPTITE JS500	2		#4 X 3/8 FLAT QUAD TYPE A JS500 BLK	4	8801 6-32 X 3/8 PAN PH TAPTITE JS500	- 2
8756 #10 X 3/4 PAN PH TYPE A BLACK OXIDE 4	8785 #8 X 3/4 OVAL PH TYPE A BLACK OXIDE	6		6-32 X 3/8 PAN PH TAPTITE JS500	2	8811 #6 X 1 1/4 FLAT QDRX WS LR CLEAR ZN	28
8781 #10 X 7/8 FLAT PHIL TYPE A JS500BLK	8815 8-32 X 3/4 PAN PH TAPTITE JS500	4		#6 X 1 1/4 FLAT QDRX WS LR CLEAR ZN	32	8785 #8 X 3/4 OVAL PH TYPE A BLACK OXIDE	11
8786 10-32 X 1 1/4 PAN QD MS JS500 BLACK	8756 #10 X 3/4 PAN PH TYPE A BLACK OXIDE	46		#8 X 3/4 OVAL PH TYPE A BLACK OXIDE	11	8815 8-32 X 3/4 PAN PH TAPTITE JS500	4
8777 #14 X 1FLAT PH TYPE A JS500 M6 HEAD	8786 10-32 X 1 1/4 PAN QD MS JS500 BLACK	8		8-32 X 3/4 PAN PH TAPTITE JS500	4	8753 #10 X 1/2 PAN PH TYPE A JS500 BLACK	14
8928 #14X11/4 ALLEN FLHD WOOD SCRW JS500	8777 #14 X 1FLAT PH TYPE A JS500 M6 HEAD	4		#10 X 3/4 PAN PH TYPE A BLACK OXIDE	58	8756 #10 X 3/4 PAN PH TYPE A BLACK OXIDE	64
7458 18" 4R 800WPGM SPEAKER	1 8928 #14X11/4 ALLEN FLHD WOOD SCRW JS500	8	8786	10-32 X 1 1/4 PAN QD MS JS500 BLACK	16	8786 10-32 X 1 1/4 PAN QD MS JS500 BLACK	8
8820 #8 FLAT WASHER JS500	8 8770 1/4-20 X 1 5/16 TRUSS PH MS JS500	10		#14X11/4 ALLEN FLHD WOOD SCRW JS500	8	8928 #14X11/4 ALLEN FLHD WOOD SCRW JS500	8
3424 DPDT SLID SW PCMT H GOLD CONTACTS	1 7458 18" 4R 800WPGM SPEAKER	1		1/4-20 X 1 5/16 TRUSS PH MS JS500	10	8846 1/4-20 X 1 3/4 FLAT PH MS JS500	16
	3424 DPDT SLID SW PCMT H GOLD CONTACTS	1		18" 4R 800WPGM SPEAKER	2	8770 1/4-20 X 1 5/16 TRUSS PH MS JS500	10
		<u> </u>		DPDT SLID SW PCMT H GOLD CONTACTS	1	7460 18" 4R1200WPGM SPEAKER DCR3.9R	1
			0121	DI DI GLID GIVI GIAN II GGLD GGIVINGTO		3424 DPDT SLID SW PCMT H GOLD CONTACTS	- 1
						3424 DFDT 3LID 3W FCWITTT GOLD CONTACTS	
	 	-	1				
	 	 	 			 	-+
	1		!				
	1		!				
	1		!				_
	1	ļ	!				
			.				
		\bot					
		1					
			1				
			1				
			1				
 	1	†	1				
 	1	†	1				
	†	†	1				
	1	-	1				
	 	-	1				_
	 	 	 			 	-
	1		!				
	I						
		1					












Note: Current model does NOT use a circuit breaker








*NOTE: Replacement grills and supports are 'Special-Order' and are only available while the model is in production.


Real Gear. Real People.






Щ	Dort#	Description			
#	Part#	Description			
Labeled	d Components				
1	Z605	LS808 GRILL			
2	Z606	LS808 GRILL BAR			
3	8929	#14X11/4 ALLEN FLHD WOOD SCRW J			
4	8259D	"Y" LOGO ELITE SERIES LARGE DOMED			
5	8483	ADAPTER, SPEAKER STAND, METAL, BLACK			
6	8565	BAR HANDLE ALL METAL			
7	8551	BAR HANDLE RIGHT ANGLE TOP LOAD			
8	18/029Y4M	18" 8R 800WPGM SPEAKER			
9	8569	CORNER. 2 LEGS NO LIP BLACK OXIDE			
10	8562	CORNER. 3 LEGS BLACK OXIDE			
11	8545	RECESSED RUBBER BUMPER WITH WASHER			
12	8579	4000 SERIES RIGID CASTER 822			
13	8551	BAR HANDLE RIGHT ANGLE TOP LOAD			
14	3924	1/4" JCK PCB MT VERT 2XTIP			
15	2419*	5.00 AMP CIRCUIT BREAKER PC MOUNT			
16	3424	DPDT SLID SW PCMT H GOLD CONTAC			
17	3628	SPKON 4C PCB MT VERT 250TAB GRY			
18	8545**	RECESSED RUBBER BUMPER WITH WAS			
19					
20					
21					
22					

- * Note: Current model does NOT use a circuit breaker
- ** Rubber feet used on 'wheeled' version









*NOTE: Replacement grills and supports are 'Special-Order' and are only available while the model is in production.

Real Gear. Real People.

